

One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HCO109 HH Air Machine Gun against defects in material or workmanship for one year from date of original purchase. The Company, at its option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warranty period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at its option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS INC.



Phone:

Toll-free: 888-318-2380

sales@hollywoodcontrols.com

© 2013 Hollywood Controls Inc 03/13 R1

Handheld Air Machine Gun Assy

Model: HCO109 Handheld Air Machine Gun & Trigger Hose

Assembly Instructions

We strive to make our equipment as reliable and long-lived as possible.

To this end, we have revised the connection hardware between the HCO109 gun and the trigger hose to provide longer service and better reliability. While the quick-connect hardware was convenient, there was a potential for winding up the RCA trigger cable and forcing it to disconnect.

The revised connection relies on several methods to make the connection tight and remain rigidly fastened. Please follow assembly steps carefully.

The new Gun has a 1/2" F-NPT PVC air connection. This mates with a 1/2" M-NPT metal barbed fitting on the hose. The metal barb is fastened with hose clamps. The entire coupling is protected with a rubber tube. The PVC fitting is positively locked to the metal fitting by a set screw.

Assembly Tools:

- Slip-Joint Pliers
- 3/32" Allen Wrench Key

Index:

Safety Precautions	1
General Description	1
Warranty	2

Assembly Steps

1. Carefully thread the hose fitting on to the PVC gun fitting. **DO NOT CROSS-THREAD!** Tighten first by hand, then, using the slip-joint pliers, firmly seat the metal fitting against the rubber gasket in the PVC fitting until it will turn no further.
2. Tighten the 10-32 Allen set screw against the threads of the metal fitting with the Allen wrench. Be firm, but do not over tighten! The gun and hose should now be rigidly connected. If there is movement of the barb in the hose, tighten the hose clamps further.
3. Extend the rubber protective hose over the metal and PVC joint.
4. Open up the loop in the RCA retaining band on the hose end RCA cable. Slip this over the gun RCA connector and plug the cables together. This will improve the retention of the RCA connectors during use. Tuck any excess cable inside the protective rubber tubing at the open end.

Safety Precautions

- **DO NOT** alter or remove labels.
- **DO NOT** place objects in the barrel outlet.
- **DO NOT** point at face.
- **DO NOT** get components wet.
- **DO NOT** connect to devices supplying power to the RCA plug.

One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HCO109 HH Air Machine Gun r against defects in material or workmanship for one year from date of original purchase. The Company, at it's option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warrantee period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at it's option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS INC.



Phone:

Toll-free: 888-318-2380

sales@hollywoodcontrols.com

© 2013 Hollywood Controls Inc 03/13 R1

Handheld Air Machine Gun Assy

Model: HCO109 Handheld Air Machine Gun & Trigger Hose

Assembly Instructions

We strive to make our equipment as reliable and long-lived as possible.

To this end, we have revised the connection hardware between the HCO109 gun and the trigger hose to provide longer service and better reliability. While the quick-connect hardware was convenient, there was a potential for winding up the RCA trigger cable and forcing it to disconnect.

The revised connection relies on several methods to make the connection tight and remain rigidly fastened. Please follow assembly steps carefully.

The new Gun has a 1/2" F-NPT PVC air connection. This mates with a 1/2" M-NPT metal barbed fitting on the hose. The metal barb is fastened with hose clamps. The entire coupling is protected with a rubber tube. The PVC fitting is positively locked to the metal fitting by a set screw.

Assembly Tools:

- Slip-Joint Pliers
- 3/32" Allen Wrench Key

Index:

Safety Precautions	1
General Description	1
Warrantee	2

Assembly Steps

1. Carefully thread the hose fitting on to the PVC gun fitting. **DO NOT CROSS-THREAD!** Tighten first by hand, then, using the slip-joint pliers, firmly seat the metal fitting against the rubber gasket in the PVC fitting until it will turn no further.
2. Tighten the 10-32 Allen set screw against the threads of the metal fitting with the Allen wrench. Be firm, but do not over tighten! The gun and hose should now be rigidly connected. If there is movement of the barb in the hose, tighten the hose clamps further.
3. Extend the rubber protective hose over the metal and PVC joint.
4. Open up the loop in the RCA retaining band on the hose end RCA cable. Slip this over the gun RCA connector and plug the cables together. This will improve the retention of the RCA connectors during use. Tuck any excess cable inside the protective rubber tubing at the open end.

Safety Precautions

- **DO NOT** alter or remove labels.
- **DO NOT** place objects in the barrel outlet.
- **DO NOT** point at face.
- **DO NOT** get components wet.
- **DO NOT** connect to devices supplying power to the RCA plug.