

Handheld Air Machine Gun



One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HC0109 HH Air Machine Gun against defects in material or workmanship for one year from date of original purchase. The Company, at its option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warrantee period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at its option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS INC.

Phone:

Toll-free: 888-318-2380

sales@hollywoodcontrols.com

© 2013 Hollywood Controls Inc 03/13 R6



Model: HC0109 Handheld Air Machine Gun & Trigger Hose

General Description

The HC0109 Handheld Air Machine Gun provides a convenient and realistic prop attachment for our PowerBlaster 3E air Cannon. The gun is attached to the trigger hose with a 1/2" NPT coupling, and an RCA plug for the trigger signal to the PowerBlaster. Please see the additional assembly instructions for proper connection of hose & gun..

If you purchased your HC0109 Handheld Air Machine Gun as part of our HC1414EKH kit, it was supplied with a HC1414EC Electronic Controller containing a custom program for the Machine Gun. This program provides 14 or 30 patterns depending on the controller model. Some of the patterns are semi-automatic, where each pull of the trigger releases a preset burst, then the trigger must be released in order to fire again. Other patterns are fully automatic. For these, the machine gun will fire a repeating pattern for as long as the trigger is pulled (or until the air runs out!) On 30 pattern models, there are additional patterns suitable for alternate installa-

Features:

- Integrated Active Trigger
- Trigger Safety Lock
- Heavy Duty Hose with Integral Trigger Cable
- RCA Plug Interface

Index:

Safety Precautions	1
General Description	1
Warrantee	2

tions using motion or pad triggers with delays.

See the sticker attached to the Controller or the insert sheet that came with these instructions for the switch settings to obtain the desired pattern and operating mode.

Strobe Light

If you also purchased our HC1200EB PowerBlaster Strobe, you can attach the strobe triggering cable to the AUX RCA jack on the HC1414EC Electronic Controller. Each time the PowerBlaster pulses the air it will also fire the strobe light. In a haunt scene, this is a very effective integration of *sound, air pressure and light that is sure to scare your guests!*

(The PowerBlaster Strobe requires a standard 120VAC power connection for the lamp power. The strobe triggering circuit is internally isolated from the strobe high-voltage supply.)

Safety Precautions

- **DO NOT** alter or remove labels.
- **DO NOT** place objects in the barrel outlet.
- **DO NOT** point at face.
- **DO NOT** get components wet.
- **DO NOT** connect to devices supplying power to the RCA plug.

One Year Limited Warranty

Hollywood Controls Inc ("the Company") warrants the HC0109 HH Air Machine Gun against defects in material or workmanship for one year from date of original purchase. The Company, at its option, will repair or replace the components and return them to you free of charge.

This warranty is extended only to the original purchaser on record with the Company.

Your remedy is limited to this warranty policy. This warranty only covers product failure that occurs due to defects in material and workmanship occurring during the normal expected use of the product. It does not cover damage caused by accident, misuse, abuse, lack of reasonable care, alterations or improper installation.

There are no expressed warranties except as described above.

THE COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so

the above exclusions or limitations may not apply to you.

No other warranty, written or verbal, is authorized by the Company. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For service during the warrantee period you must first contact the Company for an Return Merchandise Number (RMA) number. The Company will help you determine which part requires service and ask that you return that component ONLY. The Company, at its option, will repair or replace the components and return them to you free of charge. All returned components must be accompanied by a RMA number issued by the Company and be returned by insured prepaid freight. Products returned without a Company issued RMA will not be accepted. The Company is not responsible for merchandise damaged in transit. Evident or concealed damage made in transit should be reported at once to the delivery carrier and a claim filed with them.

The Company reserves the right to change or modify the operation, design, components and description of this system without notice.

HOLLYWOOD CONTROLS INC.

Phone:

Toll-free: 888-318-2380

sales@hollywoodcontrols.com

© 2013 Hollywood Controls Inc 03/13 R6



Hollywood Controls Inc.

Handheld Air Machine Gun



Model: HC0109 Handheld Air Machine Gun & Trigger Hose

General Description

The *HC0109 Handheld Air Machine Gun* provides a convenient and realistic prop attachment for our PowerBlaster 3E air Cannon. The gun is attached to the trigger hose with a 1/2" NPT coupling, and an RCA plug for the trigger signal to the PowerBlaster. Please see the additional assembly instructions for proper connection of hose & gun..

If you purchased your HC0109 Handheld Air Machine Gun as part of our HC1414EKH kit, it was supplied with a HC1414EC Electronic Controller containing a custom program for the Machine Gun. This program provides 14 or 30 patterns depending on the controller model. Some of the patterns are semi-automatic, where each pull of the trigger releases a preset burst, then the trigger must be released in order to fire again. Other patterns are fully automatic. For these, the machine gun will fire a repeating pattern for as long as the trigger is pulled (or until the air runs out!) On 30 pattern models, there are additional patterns suitable for alternate installa-

Features:

- Integrated Active Trigger
- Trigger Safety Lock
- Heavy Duty Hose with Integral Trigger Cable
- RCA Plug Interface

Index:

Safety Precautions	1
General Description	1
Warrantee	2

tions using motion or pad triggers with delays.

See the sticker attached to the Controller or the insert sheet that came with these instructions for the switch settings to obtain the desired pattern and operating mode.

Strobe Light

If you also purchased our HC1200EB PowerBlaster Strobe, you can attach the strobe triggering cable to the AUX RCA jack on the HC1414EC Electronic Controller. Each time the PowerBlaster pulses the air it will also fire the strobe light. In a haunt scene, this is a very effective integration of *sound, air pressure and light that is sure to scare your guests!*

(The PowerBlaster Strobe requires a standard 120VAC power connection for the lamp power. The strobe triggering circuit is internally isolated from the strobe high-voltage supply.)

Safety Precautions

- **DO NOT** alter or remove labels.
- **DO NOT** place objects in the barrel outlet.
- **DO NOT** point at face.
- **DO NOT** get components wet.
- **DO NOT** connect to devices supplying power to the RCA plug.